

LOG STORE

Assembly Instructions



For single, double and triple bay models

The photographs show a double bay model. Product size, configuration, roof type and timber colour may vary, but the assembly method is the same.

Check the components

Your component quantities depend on the model and any optional extras ordered. Check the delivery before starting assembly.

Single Bay	Double Bay	Triple Bay
- 2 end panels - 1 back panel - 1 base frame - Slatted floor section - 1 roof - Front roof support rail (featheredge roof only) - Doors, if ordered - Shelf and brackets, if ordered	- 2 end panels - 2 back panels - 1 rear centre post - 1 front centre post - 1 base frame - Slatted floor section(s) - 1 roof - Front roof support rail (featheredge roof only) - Doors and shelf, if ordered - Partition panel, if ordered	- 2 end panels - 3 back panels - 2 rear centre posts - 2 front centre posts - 1 base frame - Slatted floor section(s) - 1 roof - Front roof support rail (featheredge roof only) - Doors and shelf, if ordered - Partition panel(s), if ordered

Fixings and assembly aids

- 60 mm wood screws for the back panels, roof and front roof support rail
- 75 mm wood screws for the base frame
- Black screws for the latch and hook, where doors are ordered
- 2 temporary timber spacers for raising panels during assembly

The number of fixings supplied varies according to the log store size and configuration.

Assembly sequence by model

Single Bay	Attach the back panel to the first end panel, position the base frame, then fit the second end panel. No centre posts are used.
Double Bay	After the first back panel, fit one rear centre post and the second back panel. Position the base frame, then fit the second end panel and one front centre post.
Triple Bay	After the second back panel, fit the second rear centre post and the third back panel. Position the base frame, fit the second end panel, then fit both front centre posts. Secure the base frame and insert the removable slatted floor sections.

Once the frame and removable slatted floor sections are in place, fitting the roof and the featheredge front support rail (where supplied) is the same for all models.

Before you begin

Two people are recommended for safe and accurate assembly. Check that all components and fixings are present before starting.

1	Choose a firm, level base	Install on paving slabs, concrete or well-compacted gravel. Do not place the log store directly onto soil or grass.
2	Use the correct fixings	Use 60 mm wood screws for the rear panels and 75 mm wood screws for the floor frame. Use the supplied fixings for the roof.
3	Use the pre-drilled holes	The back panels, base frame, roof and front roof support rail are supplied with pre-drilled fixing holes. Insert the screws into the existing holes—no measuring or drilling is required. Check that the unit is square before fully tightening the screws.

Tools required

Cordless drill/driver, suitable driver bit, tape measure, spirit level and a step ladder where required.

Important

Do not fully tighten all fixings until the frame is correctly aligned and square. Take care when lifting the roof and larger panels.

Prepare the first side and rear panel



Position the first side panel and the first rear panel. Place the supplied temporary timber spacers beneath the rear panel so it is raised above the paving before fixing.



Secure the first rear panel to the side panel using 60 mm wood screws through the pre-drilled holes.



For double and triple bay models, position and secure the rear centre post. Single bay models do not require a centre post.



Place timber spacers beneath the next rear panel and secure it to the rear centre post using 60 mm wood screws. For triple bay models, fit the second rear centre post before positioning and securing the third rear panel.



Place the floor frame inside the assembled side and rear sections. Ensure it sits squarely and in the correct orientation.



Position the remaining side panel and secure the final rear panel to it through the pre-drilled holes.



Fit the front centre post for each division, then secure the complete floor frame using 75 mm wood screws through the pre-drilled holes.



Place the slatted floor sections inside the floor frame. Do not screw them down: they are designed to be lifted or tilted for cleaning.



Position the roof evenly, check the overhang, then secure it through the pre-drilled holes using 60 mm wood screws.



Position the supplied front support rail beneath the front roof overhang. Insert the 60 mm wood screws through the existing pre-drilled holes and fix the rail to both end panels and to the front centre post(s). It covers the roof-batten ends, adds rigidity and gives a neat finish. Felt-roof models do not use this rail.

Optional extras

Doors, shelves and partitions are suitable for single, double and triple bay models. Separate fitting instructions are provided for optional extras, so this main assembly guide does not need to be changed.

Need help?

If you are unsure which instructions apply to your product, please contact RA Garden Ideas and include your order number.